

Apple Remote Control Manual

Model: AP1868AL

About your Apple Remote


- Your Apple Remote (aluminum or white) uses IR technology (Infrared). If there are nearby Apple devices with IR (like a Mac or second Apple TV), link your remote to your primary Apple TV to prevent interference. If not, you don't need to link your remote.

- You can link your Apple Remote (aluminum or white) only to an Apple TV (3rd generation or earlier).

Siri Remote and Apple TV Remote*

work with only one Apple TV at a time and don't support Apple TV (2nd or 3rd generation).


- Under the default setting, AP1868AL can directly control many TV brands, **(SAMSUNG/LG/SONY/TOSHIBA/VIZIO/PHILIPS/PANASONIC)**. **[TV POWER]/[INPUT]/[VOL+]/[VOL-]/[MUTE]** Work for TV



Compatible Types Picture




Battery install



Use your new Apple Remote

1. Open your apple TV
2. Use the Our Apple Remote (silver), Press and hold the [MENU] and [Left] buttons for 6 seconds.




Learning function


It only learn Infrared remote control function, can not learn bluetooth and wireless remote control to learn.

If there are five buttons that don't function, please use the original remote control to learn


To learn, firstly make sure you have all your original remote controls to hand, and that they have working batteries in. To learn functions, the original remote should be approximately 3cm from the AP1868AL remote, pointing towards it as shown below:



Step.1: Press [] + [VOL+] together for 5 seconds until LED light is lit.



Step.2: Press and hold the key on the original remote, the LED light will blink. Press and hold the key you want to learn a function onto AP1868ALC, the LED light will blink three times and stay lit. Release both keys.




Step.3: Repeat part.2 to learn other the keys you want to learn. (If have some buttons not work, please learn again)

Step.4: Press [] + [VOL-] together one second LED light is on to save setting.

Hints: if no keys pressed in 25 secs, it will exit from learning mode.

Default Mode

- Restore to the default setting, please and hold the [Input] and [up] buttons about 6 seconds, the LED light will be blink three times, now it is in default setting.



Return to the last time learned Mode

If you already learned remote control before, now you want to return last time learn state, you need to make the following setting.

- Please and hold the [Input] and [down] buttons about 6 seconds, the LED light will be blink three times, now it is in last time learn state.

