Thank you for choosing our product. To begin, install two AAA 1.5V alkaline batteries and pair the remote with your TV using the steps below to ensure seamless operation.

## **Product Compatibility & Functions**

This remote control ERF6B80H is compatible with Hisense Google TV and Android TVs.

Infrared (IR) Functions: Ready for immediate use once batteries are installed.

Voice Function: Requires pairing as described below.

#### **Pairing Instructions (for Voice Control):**

#### 1. Power On & Prepare

- Turn on your TV.
- If your TV is currently paired with an old remote control, it is recommended to unpair it first.(See Note below for unpairing steps)
- Ensure the TV is connected to the internet and Bluetooth is turned on.
- Keep the remote control within 10 feet (3 meters) of the TV during pairing.

#### 2. Access Bluetooth Settings

Navigate to Settings > Bluetooth > Remote & Accessories > Pair Remote Control

- The exact path may vary. Look for options like "Bluetooth", "Accessories", or "Remote".
- To unpair the old remote, select it from the paired devices list and choose "Unpair".

## 3. Activate Pairing Mode

Press and hold the buttons until the LED indicator flashes red.

**Note**: Point the remote at the TV during the process.

# 4. Complete Pairing

The pairing process will start automatically. When "Pairing successful" appears, press and hold the **Voice Control** button to test if the voice command feature is working.

## 5. **Verify Status**

- Success: LED flashes blue upon button press.
- Failure: LED remains red. Repeat the pairing process (Steps 1-4).

## /\ Note:

- When the TV is turned off, pressing any key on the remote control will illuminate the red light, this is normal. The blue light will be displayed after being turned on again.
- If the blue light appears dim or fails to illuminate, replace the Alkaline batteries promptly.